

Windpro™ Hurricane Banner Bracket System Mounting Instructions



Suggested Tools:

Tape
4mm Allen wrench
Tin Snips
Hammer
Flat Screwdriver **Screw gear banding only**
Band-It® Tool **For use with optional Band-It® Banding only**

Windpro™ Hurricane Bracket with Screw Gear Banding



1. Use tape to hold base plate to pole while you apply banding. Always attach upper base plate and arm first. Be sure the word "Top" is pointing up.



2. Slide banding through snaplock and tighten with a screwdriver.



3. Cut off excess banding with tin snips.



4. Center an arm into the top base plate with the word "Banner" pointing toward the banner and tighten the set screws. The top pole should be canted up with no banner in place.



5. Slide banner onto top pole and secure with provided "zip tie".



6. With the banner hanging from the top arm, attach lower base plate so that the bottom of the banner falls just below the lower set screw.



7. Slide lower arm into banner so that the word "banner" points to the banner. Secure the banner to the arm with the provided "zip tie".



8. Rock the arm into the base plate by lifting up and down on the outer end of the arm while pulling down on the inside until banner is tight and tighten set screws. DO NOT hammer on the casting, this will void warranty.

Windpro™ Hurricane Banner Bracket System Mounting Instructions

Windpro™ Hurricane Bracket with Optional Band-It® Banding



1. Cut a piece of banding long enough to wrap around the pole and bracket either for a single wrap or double wrap. Be sure to add at least 6 extra inches to apply clamping tool.



2. Bend end of band back.



3. Slide buckle up into the fold on the band and tap a crease in the band with a hammer if necessary.



4. Use tape to hold base plate to pole while you apply banding. Always attach upper base plate and arm first. Be sure the word "Top" is pointing up.



5. Single wrap or double wrap banding around pole (see banding guidelines for more info on wrapping requirements).



6. Apply the banding tool to tighten, fold, and cut the band according to instructions included with the Band-It® tool.



7. Use a hammer to fold the band over the buckle and then pound tabs of the buckle over the band.



8. Center the arm in the base plate with the word "Banner" pointing toward the banner and tighten the set screws. The top pole should be canted up with no banner in place.



9. Slide banner onto top pole and secure with provided "zip tie".



10. With the banner hanging from the top arm, attach lower base plate so that the bottom of the banner falls just below the lower set screw.



11. Slide lower arm into banner so that the word "banner" points to the banner.



12. Rock the arm into the base plate by lifting up and down on the outer end of the arm while pulling down on the inside until banner is tight and tighten set screws. DO NOT hammer on the casting, this will void warranty.