

WindPro® Hurricane Banner Bracket Warranty

WindPro® Hurricane Banner Brackets are warranted for ten (ten) years, from the date of invoice against defects in material and workmanship when installed according to WindPro Hurricane installation instructions, banding guidelines and when used to support banners 30" x 96" or smaller.

We recommend the use of Band-It® stainless steel banding (# C206) or equivalent on our Hurricane brackets. The banding should be wrapped twice around the pole and casting assembly before clamping the buckle. Brackets should be inspected 30 days after initial installation and every 60 days thereafter, immediately making adjustments as needed. This warranty does not apply when installation performed and/or equipment used is contrary to WindPro's® specifications and instructions, nor where equipment is altered or modified. Excessive force, i.e. hammering bracket into place is not necessary, will damage the castings and void the warranty. This warranty does not cover installation or removal costs incurred by customer. WindPro Hurricane Brackets are warranted to withstand wind gusts up to 70 MPH when used with banners measuring 30" wide by 96" or smaller.

WindPro Hurricane Brackets sold with screw gear banding are warranted for a period of two (2) years from the date of invoice against defects in material and workmanship when installed according to WindPro Hurricane installation instructions, banding guidelines and when used to support banners 30" x 96" or smaller. We do not offer a warranty on the 9/16" Screw gear banding.

WindPro Hurricane Banner Bracket Hardware Banding Guidelines

Standard 9/16th SGB Bands



1 BANNER
PER POLE:



2 BANNERS
PER POLE:



3/4" Single



1 BANNER
PER POLE:



2 BANNERS
PER POLE:



not to scale

3/4" Double Wrap



1 BANNER
PER POLE:



2 BANNERS
PER POLE:



not to scale

Banding Options:

9/16" Screw Gear Bands (SGB)

Single Wrap of 3/4" tool-applied banding

Double wrap of 3/4" tool-applied banding

Q. How much banding do I need?

- A.** Measure around the pole with a tape measure. (This is the circumference.) Add 6 inches (for tightening). Now multiply that by 4 (4 bands per pole). Now multiply that by how many poles you are going to banner. That's your answer for ; for double-wrap, multiply again by 2.

Banner Size* Inches	30x60		30x72		30x84		30x96		30x120	Maximum Single Banner Size SF	Maximum Total Sq. Ft. for 2 Banners per Pole
	1	2	1	2	1	2	1	2			
9/16" SGB	YES	NO	N/R	NO	NO	NO	NO	NO	NO	12.5	16
Single Wrap 3/4"	YES	NO	YES	NO	YES	NO	YES	NO	NO	20	25
Double Wrap 3/4"	YES	YES	YES	YES	YES	YES	YES	YES	YES	25	30

YES - will work in typical wind conditions 70 mph
NO - will not perform long term in typical wind conditions
N/R - will work but not recommended

*Mounting banners larger than the maximum recommended size will void warranty

**No warranty on 36" rods/banners